



Don't worry, the brand is Wald™
No se preocupe, la marca de fábrica es Wald™



WIRE REAR FOLDING BASKET

CESTA DEL ALAMBRE QUE
DOBLA AL POSTERIOR

- Release **1** latch on top of basket.
- Open basket and push bottom down until **2** hook rests on bottom basket wire.
- With latch side of basket against the rack, place the two **I** shaped clamps on the basket top wire (flat side of clamp toward rack), then slide clamps down onto the rack. Assemble bolts and nuts.
- Using the "U" clamp, fasten a side basket wire near the bottom to rack leg. Assemble bolt and nut.
- When not in use, raise bottom up against the side, fold ends in and push front of basket flat against the back. Fasten with **1** latch.

- Lance el cierre **1** encima de la cesta.
- Abra la cesta y empuje el fondo abajo hasta **2** que el gancho se base sobre el alambre inferior de la cesta.
- Con el lado del cierre de la cesta contra el estante, coloque las dos **I** abrazaderas formadas en el alambre de la tapa de la cesta (el lado plano de la abrazadera hacia el estante), entonces resbale las abrazaderas abajo sobre el estante. Monte los pernos y las tuercas.
- Usando la abrazadera "U," sujete un alambre lateral de la cesta cerca del fondo a la pierna del estante. Monte el perno y las tuercas.
- Cuando no en uso, levante el fondo para arriba contra el lado, doble los extremos adentro y empuje el frente del plano de la cesta contra la parte posterior. Sujete con el cierre **1**.